

4. SOLDER THE CONTACT ONTO THE CENTER CONDUCTOR, PER

AGAINST THE CABLE DIELECTRIC. CLEAN ALL FLUX RESIDUES

THE CABLE JACKET, LEAVING AS MUCH WEAVE AS POSSIBLE.

ં ા ા

EVERY 1/8". GENTLY ROTATE PIN TO SEPARATE THE FLAT FOIL

BRAID AND ALUMINUM/POLYESTER FOIL FROM THE DIELECTRIC.

USING TWEEZERS, FOLD BACK ALUMINUM/POLYESTER FOIL

USING TWEEZERS, FOLD THE INNER BRAID BACK OVER THE

NOTE: TAKE CARE NOT TO UNRAVEL DIELECTRIC WHEN

THE OTHER BRAIDS, LEAVING AS MUCH WEAVE AS POSSIBLE.


MIL-STD-2000, USING 63Sn/37Pb SOLDER OR CRIMP

WITH Y1757 DIE. ENSURE THE CONTACT IS BUTTED

5. USING TWEEZERS, FOLD THE OUTER BRAID BACK OVER

6. SLICE THE ALUMINUM/POLYESTER FOIL LENGTHWISE ABOUT

USING AN APPROPRIATE FLUX CLEANER.



REVISIONS

APPROVED

DATE

10/2/16 12/5/18

DESCRIPTION

OVER THE OUTER BRAID.

PULLING BACK INNER SHIELD.

2

10/2/06 SCALE:

1

FILE NO F:\E\SPEC\CONN\INST\CCR002

SHEET: 1 OF 1